## ECLIPSE AMNION MEMBRANE TISSUE

**EASY APPLICATION INSTRUCTIONS** 



**OPHTHALOGIX** 

an Evologics Company

www.ophthalogix.com

NEED TO PLACE AN ORDER? GO TO WWW.OPHTHALOGIX.COM OR CALL (888) 77-AMNION



## EASY APPLICATION INSTRUCTIONS

## **REQUIRED MATERIALS**

- ANESTHETIC DROPS
  ANTIBIOTIC DROPS
- STERILE GLOVES
  STERILE FORCEPS
  - WECK CELL, Q-TIPS



## INSTRUCTIONS FOR USE

- PLACE UNOPENED TISSUE, CONTACT LENS CASE, FORCEPS, Q-TIP AND OTHER MATERIALS NEEDED ON WORKSPACE. KEEP THE MEMBRANE COVERED UNTIL YOU ARE READY FOR PLACEMENT.
- 2. IF USING AN EYE SPECULUM PLACE IT NOW.
- INSTILL ONE DROP OF TOPICAL ANESTHETIC TO EYE, FOLLOWED BY ONE NON-VISCOUS TOPICAL ANTIBIOTIC DROP.
- 4. USE SOFT CELL/WECK CELL SPONGE TO DRY CORNEAL SURFACE.
- CAREFULLY OPEN POUCH (TISSUE IS VERY LIGHTWEIGHT AND CAN EASILY BE DROPPED).
- USE SMOOTH TIP FORCEPS AND REMOVE TISSUE FROM POUCH (GROOVED FORCEPS CAN DAMAGE THE TISSUE).
- PLACE GRAFT CENTRALLY ON CORNEA; USING SPONGE OR SIDE OF FORCEPS TO SMOOTH GRAFT TO CORNEAL SURFACE.
- 8. REMOVE CONTACT LENS FROM CASE, PLACE LENS OVER CORNEA.
- INSTRUCT PATIENT TO KEEP EYES CLOSED FOR TWO-THREE MINUTES WITHOUT RUBBING EYES.
- INSTRUCT PATIENT TO USE APPROPRIATE EYEDROPS FOR LUBRICATION AND ANTIBIOSIS, PLAN TO SEE PATIENT IN 3-4 DAYS, SOONER IF THE PATIENT DISCOMFORT / REDNESS / SWELLING.